

Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://victor.nt-rt.ru/> || [vtd@nt-rt.ru](mailto:vtd@nt-rt.ru)

## VICTOR 4000M Фазовый вольт-амперметр



### Описание:

Model	4000M
Function	On-line test the phase, voltage, current, leakage current, frequency, phase sequence etc. in the 380/220V electric system
Power apply	6LR61, 9V DC, working continuously for 20h
Clamp size	Φ 7.5mm×13mm
Measurement range	Phase: 0~360° , voltage: 0~600V, current: AC 0.00mA~30.0A, frequency: 0~400Hz
Resolution	Phase 1° ; voltage: 0.01V; current: 0.01mA; frequency: 0.1Hz
Accuracy	Phase: ± 3° ; voltage: ± 2% ± 3dgt; current: ± 2% ± 3dgt; frequency: ± 1Hz
Data storage	99 sets
Meter size	Length width thickness 220mm×45mm×30mm
Line voltage	to test below 600V
Function conversion	To convert by MODE key, will display phase, voltage, current, frequency; Booting default is phase
Data hold	Hold the data by HOLD key, cancel holding by HOLD key again
Data check	to enter the data check function by READ key, look over the storage data by up or down arrow key
Automatic shutdown	After startup about 15mins, the instrument will be automatically shut down to reduce battery consumption
Meter mass	Meter: 220g (include battery); total mass: 400g
Working current	Max × 100mA