

Архангельск (8182)63-90-72
 Астана (7172)727-132
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
 Тверь (4822)63-31-35
 Томск (3822)98-41-53
 Тула (4872)74-02-29
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70


Казахстан (772)734-952-31

<https://victor.nt-rt.ru/> || vtd@nt-rt.ru

VICTOR 690 Clamp Leaker



Description:

	Model 690
Power Source	Zinc-manganese dry battery 6F22 9V
Test Mode	Flexible CT: the output signal is the differential of the current to the time. By integrating the output voltage signal, the input current can be truly restored.
Coil Diameter	200mm diameter
Range	AC 0.00A~9999A
Resolution	AC 10mA
Accuracy	±2%+3dgt(The wire is in the center of the flexible coil,23°C ± 2°C)
Coil thickness	7.5mm (Very suitable for narrow environments and places with dense wiring)
Measured Current Frequency	50Hz/60Hz (automatic identification)
Data Storage	99units, all used when display FULL
Peak Value Hold	Push HOLD without release, the meter will show the peak value during the pushing period, display 
Data Hold	DH indicating the reading is hold
Line Voltage	circuit test below AC1600V