

Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://victor.nt-rt.ru/> || [vtd@nt-rt.ru](mailto:vtd@nt-rt.ru)

## VICTOR 6800 Clamp Leaker



### Description:

	Model 6800
Range	0.00mA~1200A
Resolution	0.01mA
Accuracy (23℃±3℃, below 70%RH)	0.00mA~59.9A: ±1.5%±5dgt 60.00A~199A: ±2%±5dgt 200.0A~599A: ±3%±5dgt 600A~1200A: ±4%±5dgt
Power	Zn-Mn dry battery.6F22.9V
Size of jaw	Φ68mm
Sampling Rate	about 2 times/s
USB Interface	Data stored in the memory of the meter via USB upload to PC, or on-line monitoring
Storage	99units, all used when display FULL
Peak Hold	Push HOLD without release, the meter will show the peak value during the pushing period
Reading Hold	DH indicating when the reading is hold
Out of Range	OL indicating when the current is out of range
Working Current	5mA
Line Voltage	circuit test below AC1600V
Range Shift	Automatically