

Архангельск (8182)63-90-72
 Астана (7172)727-132
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
 Тверь (4822)63-31-35
 Томск (3822)98-41-53
 Тула (4872)74-02-29
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://victor.nt-rt.ru/> || vtd@nt-rt.ru

Утечка цифровых клещей VICTOR 140

ID предмета # 140



Описание:

Function	Measurement of AC leakage current, AC current and on-line AC current
Power	DC3V Button-type battery LR-44×2 or SR-44×2
Test Mode	Clip-on CT, integral mode
Display Mode	Four Bits LCD display
Dimension	Width × Height × Thickness: 64mm × 160mm × 23mm
LCD Dimension	35mm × 21.5mm; display domain: 32mm × 15mm
Clamp Mouth	φ40mm
Sampling Rate	about 2 times/s
Range	0.00mA ~ 300.0A (50/60Hz)
Resolution	- 4 - 0.01mA

Technical specifications (Continuous form)

Measuring range	30mA/300mA, 30A/300A, second-range manual switch, Automatic switch in all ranges
Measurement accuracy	0.00mA ~ 9.99mA: ±1.2% ± 5dgt 10.0mA ~ 300.0mA: ±1.5% ± 5dgt
(below 23°C ± 1°C, 70%RH)	0.00A ~ 9.99A: ±1.2% ± 5dgt
	10.0A ~ 99.9A: ±1.5% ± 5dgt
	100.0A ~ 199.9A: ±2% ± 5dgt
Line voltage	200.0A ~ 300.0A: ±4% ± 5dgt Line test under AC600V
Data Storage	60 groups, "FU" symbol flickering means storage is full

Peak Holding	Peak value capture and holding function, press HOLD button continually to show peak value in the course of testing.
Data Holding	Data holding function: displayed by “ DH ” symbol
Overflow display	- 5 - Outrange overflow display: displayed by “ OL ” symbol

Technical specifications (Continuous form)

Automatic shutdown	After starting up the leaker for 5 minutes, it will shut down automatically to reduce battery consumption.
Battery voltage	When battery voltage reduced to 2.5V~2.7V, battery low voltage symbol will filker to remind replacing battery; at this time, measurement accuracy will decrease.
Leaker Quality	About 120g (with battery)
Rating Power	about 5mW
Working temperature and humidity	-0°C~40°C; below 80%rh
Storage temperature and humidity	-10°C~60°C; below 70%rh
Insulation strength	AC2kV/rms (between core and box)
Applicable safety rules	IEC1010-1、IEC1010-2-032、pollution, etc 2、CAT III (600V)

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31