

(8182)63-90-72
(7172)727-132
(8512)99-46-04
(3852)73-04-60
(4722)40-23-64
(4832)59-03-52
(423)249-28-31
(844)278-03-48
(8172)26-41-59
(473)204-51-73
(343)384-55-89
(4932)77-34-06

(3412)26-03-58
(395)279-98-46
(843)206-01-48
(4012)72-03-81
(4842)92-23-67
(3842)65-04-62
(8332)68-02-04
(861)203-40-90
(391)204-63-61
(4712)77-13-04
(4742)52-20-81

(3519)55-03-13
(495)268-04-70
(8152)59-64-93
(8552)20-53-41
(831)429-08-12
(3843)20-46-81
(383)227-86-73
(3812)21-46-40
(4862)44-53-42
(3532)37-68-04
(8412)22-31-16

(342)205-81-47
(863)308-18-15
(4912)46-61-64
(846)206-03-16
(812)309-46-40
(845)249-38-78
(8692)22-31-93
(3652)67-13-56
(4812)29-41-54
(862)225-72-31
(8652)20-65-13

(3462)77-98-35
(4822)63-31-35
(3822)98-41-53
(4872)74-02-29
(3452)66-21-18
(8422)24-23-59
(347)229-48-12
(4212)92-98-04
(351)202-03-61
(8202)49-02-64
(4852)69-52-93

(996)312-96-26-47

(495)268-04-70

(772)734-952-31

<https://victor.nt-rt.ru/> || vtd@nt-rt.ru

e VICTOR 852E

852



Описание:

Specification:

Measuring Range: 0-1250 μ m/ 0-50mil

Resolution: 0.1 μ m / 0.1mil

Accuracy: $\pm(2\%+2\mu\text{m})$ / $\pm(2\%+0.1\text{mil})$

Product Size: 166 x 68 x 30mm 6.5x 2.5 x 1 inch

Product Weight: 180g/ 0.4 lb(with batteries)

Operation Temperature: -10 to +50°C(+12 to +122°F)

Note: Only take measurement after the probe of the instrument reaches environment temperature. Please disregard the first several readings if you are not sure whether the probe is stable under current environment temperature.